

*This mat has an aggressive adhesive. Take care when installing and beware as large adjustments are not possible once the mat has adhered to floor. If you have applied less than 1/4 of the mat and need to make a small adjustment, slightly warm the adhered area with a hair dryer and try to reposition the mat.*

*Do not attempt to pull the paper from the mat all at once and apply. Follow all instructions in order and carefully.*

*If trimming is necessary, mark trim lines on the liner on the back of the mat. Trim with household scissors instead of a knife.*

- 1. Thoroughly clean the tub surface under where you will place the mat. You can use almost any household cleaner.*
- 2. Rinse the surface and let it completely dry.*
- 3. Without removing the backer, place the mat on the tub floor where you want it to go.*
- 4. With a pencil, mark the floor surface at the corners of the mat.*
- 5. Pull back 6" of the backer from one end, exposing the adhesive.*
- 6. Carefully align the mat starting at one end, using the pencil marked corners as a guide to keep it straight.*
- 7. Press down on the mat to secure one end to the tub floor.*
- 8. Keeping the mat tight, pull off the backer, adhering small portions.*
- 9. Continue this until the entire mat is placed down. If you attempt to apply the mat flat to the whole tub bottom, you will end up with bubbles. The mat cannot be pulled back up and reapplied.*
- 10. Press down with your hands on the entire mat so all parts are stuck to the tub floor.*
- 11. If there are any small bubbles, use a credit card or the edge of a hardcover book to firmly squeeze them toward the edges.*

## Application Instructions

*Este tapete tiene un adhesivo agresivo. Tenga cuidado durante la instalación y tenga en cuenta que no es posible realizar ajustes mayores una vez que el tapete se ha adherido al suelo. Si ha aplicado menos de 1/4 del tapete y necesita realizar un ajuste pequeño, caliente levemente el área adherida con una secadora de pelo e intente reubicar el tapete.*

*No intente jalar el papel del tapete de una vez y aplicar. Siga todas las instrucciones en orden y con cuidado.*

*Si necesita recortar, marque las líneas de recorte en el revestimiento de la parte posterior del tapete. Recorte con tijeras para el hogar en lugar de un cuchillo.*

- 1. Limpie completamente la superficie de la tina donde colocará el tapete. Puede utilizar casi cualquier limpiador doméstico.*
- 2. Enjuague la superficie y déjela secar completamente.*
- 3. Sin retirar el respaldo, coloque el tapete en el piso de la tina en el lugar deseado.*
- 4. Marque la superficie del piso con un lápiz en las esquinas del tapete.*
- 5. Retire 15,24 cm del respaldo en un extremo, revelando el adhesivo.*
- 6. Alinee cuidadosamente el tapete comenzando en un extremo, utilizando las esquinas marcadas con lápiz como guía para mantenerlo derecho.*
- 7. Presione el tapete para asegurar un extremo al suelo de la tina.*
- 8. Sosteniendo el tapete firmemente, retire el respaldo y adhiera partes pequeñas.*
- 9. Continúe haciendo esto hasta haber colocado el tapete completo. Si intenta aplicar el tapete de manera plana en el piso de la tina, terminará con burbujas. El tapete no se puede extraer y volver a aplicar.*
- 10. Presione con las manos el tapete completo para que todas las partes se adhieran al piso de la tina.*
- 11. Si hay alguna burbuja pequeña, use una tarjeta de crédito o el borde de un libro con tapa dura para apretarlas firmemente hacia los bordes.*

## Instrucciones de aplicación